

WeatherBond

Flexible DASH Adhesive



Overview

WeatherBond's VOC-free, energy-absorbing, impact resistant Flexible DASH Adhesive is for use with Fleece membranes and to secure insulation boards to the deck for a totally non-penetrating system application. This industry-leading breakthrough in urethane adhesive technology offers built-in elongation and energy-absorbing properties that work in conjunction with the Fleece membrane to enhance puncture and hail resistance. Flexible DASH Adhesive is applied in full spray, splatter, or extrusions to deliver the two components onto the substrate. Parts A & B are mixed in the spray gun and applied to the roof. A catalytic reaction takes place, causing the Flexible DASH Adhesive to expand and foam. WeatherBond's Fleece membrane is then laid into the foamed adhesive after developing "string/body" and rolled with a 150-lb. segmented roller to ensure the fibers of the fleece are embedded into the adhesive. Within 20 minutes, Flexible DASH Adhesive cures to form a tenacious bond between the substrate and the Fleece membrane.

Features and Benefits

Added Puncture Resistance

In side-by-side dynamic puncture tests, Flexible DASH Adhesive increased puncture resistance between 33 – 50% compared to traditional competitive 2-component low-rise adhesives. The energy absorbing nature of the Flexible DASH foam makes this an ideal product for use in Roof Garden, Plaza Paver and Solar Panel applications in conjunction with Fleece membrane.

- FM approved

Energy Efficient and Environmentally Sound

Each layer of Flexible DASH Adhesive expands to $\frac{1}{16}$ " – $\frac{1}{8}$ "-thick and provides an additional R-value of 0.20 to 0.50 per layer. The NRCA estimates that up to 10% of R-value can be lost due to joints in the insulation. The expanding nature of DASH adhesive helps to seal insulation joints, when Flexible DASH Adhesive is specified for insulation attachment in place of mechanical fasteners, the 3 – 8% loss in R-value can be eliminated. Water is used as the blowing agent in Flexible DASH Adhesive, making it VOC compliant and not labeled as a flammable product.

Superior Wind Uplift

Superior wind uplift resistance is delivered with uplift pressures ranging from 90 – 945 psf depending on the substrate.

Expedient Installations without Interruption

Due to the low noise and low odor associated with the system, the Fleece/Flexible DASH assembly is an excellent choice for re-roofing occupied buildings, as there is minimal disruption. Because of these benefits, schools, universities and hospitals are some of the biggest users of the Fleece/Flexible DASH assembly. The speed of application with Flexible DASH Adhesive affords project completion in a timely manner. Flexible DASH offers a significant reduction in free MDI: from 32% to 23% compared to traditional urethane adhesives.

Application

1. The surface to which adhesive is to be applied shall be dry and free of fins, protrusions, sharp edges, loose and foreign materials, oil and grease. Depressions greater than $\frac{1}{4}$ " (6 mm) shall be filled with Flexible DASH Adhesive or other approved patching material. All sharp projections shall be removed.
Previously unweathered asphalt must be primed with CAV-GRIP™ III.
2. **Seal gaps between the wall/penetration and concrete deck with 725TR, or other suitable material, to avoid condensation issues and positive pressure from air infiltration.**
3. For re-roofing sprayed-in-place (SPF) urethane roofs, all wet areas must be removed. The surface must then be scarified or perforated, depending on the coating, before applying Flexible DASH Adhesive.
4. Apply Flexible DASH Adhesive when the substrate and ambient temperatures are 25°F (-4°C) or above when spraying or extruding with heated or non-heated equipment. Dispense the adhesive between 300–800 psi, depending on the equipment used. Consult with your local Fleece Specialist for more details.
5. Set pre-heater and hose temperature to 120°F (49°C). Temperature settings will vary with conditions.



WEATHERBOND
ROOFING SYSTEMS

Single-Ply Simplified

Fleece Installation

Slide-in Method :

1. Unroll Fleece sheet and position. Fold the sheet back in half lengthwise (end-to-end).
2. Spray-apply, splatter, or extrude Flexible DASH Adhesive to the substrate.
 - a. For full spray applications, spray adhesive at 1-gallon per square to obtain full coverage (approximately ¼" to ½" thick after foaming). Ensure membrane end laps are protected from adhesive.
 - b. For splatter applications, spray adhesive at ½ gallon per square to obtain 50% coverage (approximately ¼" to ½" thick after foaming). Ensure membrane end laps are protected from adhesive.
 - c. For extruded applications, apply at 4", 6", or 12" on center with a minimum ½" bead. Ensure membrane end laps are protected from adhesive.
3. Once "string time" occurs, gradually feed Fleece sheet into Flexible DASH Adhesive, checking for "string/body" every few feet. Stop feeding Fleece sheet into adhesive when applicator reaches adhesive that has NOT developed "string/body". Immediately begin to roll membrane width-wise with a 150-lb. segmented weighted roller. Repeat process until Fleece sheet is fully installed.

Roll-in (Mod Bit) Method:

1. Keeping the Fleece sheet on the core, position roll of Fleece membrane at the designated starting point.
2. Spray-apply, splatter, or extrude Flexible DASH Adhesive to the substrate.
 - a. For full spray applications, spray adhesive at 1-gallon per square to obtain full coverage (approximately ¼" to ½" thick after foaming). Ensure membrane end laps are protected from adhesive.
 - b. For splatter applications, spray adhesive at ½ gallon per square to obtain 50% coverage (approximately ¼" to ½" thick after foaming). Ensure membrane end laps are protected from adhesive.
 - c. For extruded applications, apply at 4", 6", or 12" on center with a minimum ½" bead. Ensure membrane end laps are protected from adhesive.
3. Once "string time" occurs, gradually roll Fleece membrane into Flexible DASH Adhesive, checking for "string/body" every few feet. Stop rolling Fleece into adhesive when applicator reaches adhesive that has NOT developed "string/body". Immediately begin to roll membrane width-wise with a 150-lb. segmented weighted roller. Repeat process until Fleece sheet is fully installed.

Insulation Attachment

1. Apply Flexible DASH Adhesive to the substrate achieving a light-blue-colored foam.
 - For full spray applications, spray adhesive at 1-gallon per square to obtain full coverage (approximately ¼" to ½" thick after foaming). Ensure membrane end laps are protected from adhesive.
 - For splatter applications, spray adhesive at ½ gallon per square to obtain 50% coverage (approximately ¼" to ½" thick after foaming). Ensure membrane end laps are protected from adhesive.
 - For extruded applications, apply at 4", 6", or 12" on center with a minimum ½" bead. Ensure membrane end laps are protected from adhesive.

Bead Spacing parameters for 55-mph wind speeds:

Building Height	Bead Spacing (Perimeter)	Bead Spacing (Field)
0' – 25'	6" o.c. (4' perimeter)	12" o.c.
26' – 50'	6" o.c. (8' perimeter)	12" o.c.
51' – 75'	6" o.c. (12' perimeter)	12" o.c.
76' – 100'	6" o.c. (16' perimeter)	12" o.c.
101' or greater	6" o.c. (24' perimeter)	12" o.c.

2. Factory Mutual bead spacing guidelines in the perimeter and corner may differ from the table above. Beads at 12" o.c. are not acceptable at perimeters and corners.
3. Allow Flexible DASH Adhesive to rise and develop "string/body" (approx. 1½ – 2 min.). String time will vary based on environmental conditions like temperature and humidity. Do not allow the adhesive to over-cure prior to setting insulation boards.
4. Place insulation boards (maximum 4' x 4' insulation boards when adhesive is extruded at 12" o.c. or when boards exceed 4" thickness, or 4' x 8' insulation boards when adhesive is applied in full spray, 4", or 6" beads) into adhesive after allowing it to rise and develop "string/body". String time will vary based on environmental conditions like temperature and humidity. Do not allow the adhesive to over-cure prior to setting insulation boards.
5. Designate one person to walk boards into place and then roll the boards between 5 – 7 minutes from the initial adhesive application. Boards may be temporarily weighted or relief-cut where necessary to keep the boards in constant contact with the adhesive until the adhesive cures.
6. At the beginning of the insulation attachment process and periodically throughout the day, check the adhesion of boards to ensure a tight bond is created and maximum contact is achieved.

REVIEW CURRENT WEATHERBOND INSTALLATION INSTRUCTIONS FOR SPECIFIC APPLICATION REQUIREMENTS.



WEATHERBOND
ROOFING SYSTEMS

Single-Ply Simplified

Precautions

1. Review the Safety Data Sheet for complete safety information prior to use.
2. The foam produced is an organic material. It must be considered combustible and may constitute a fire hazard. The foam adhesive must not be left exposed or unprotected. Shield from heat and sparks.
3. Do not smoke during application.
4. Use with adequate ventilation. Avoid breathing vapors. Wear a NIOSH- or MSHA-approved respirator for organic vapors with prefilters and solvent-resistant cartridges or supplied airline respirators while spraying. Proper safety training is essential for all persons involved in the installation process. If vapor is inhaled, remove to fresh air and administer oxygen if breathing is difficult. Consult a physician immediately.
5. Avoid contact with eyes. Safety glasses or goggles are required.
6. If Flexible DASH adhesive is splashed in eyes, immediately flush eyes with plenty of clean water for at least 15 minutes. Contact a physician immediately.
7. Avoid contact with skin. Wear long-sleeved shirts and long pants. Wash hands thoroughly after handling. In case of contact with skin, thoroughly wash affected area with soap and water or corn oil. NOTE: Permeation-resistant gloves that meet ANSI/ISEA 105-2005 are required when handling the material or during application.
8. Jobsite storage temperatures in excess of 90°F (32°C) may affect product shelf life. When temperatures are in excess of 90°F (32°C), utilize white membrane or material to shield the drums from direct sunlight. When storing or using adhesive in temperatures below 60°F, the adhesive internal temperature must be returned to 70°F prior to use. Placing adhesive in a heated area (70 – 90°F) for 4 hours should allow liquid adhesive to reach 70 – 90°F.
9. Use spray booths, windscreens and/or lower spray pressure with spatter tips when spraying.
10. Precautions must be taken to prevent Flexible DASH Adhesive vapors or overspray from entering buildings during application. All air-intake vents on roofs must be closed during application of adhesive.
11. Use desiccant dryers on Part A drums to avoid formation of crystals from exposure to moisture in the air.
12. Desiccant dryers should be used to prevent atmospheric moisture contamination of the remaining diisocyanate. Even a small amount of contamination by water or other foreign substance could result in excess pressure and catastrophic failure of the jug container. Do not reseal a jug if contamination is suspected. Move container to a well-ventilated area (outside) and allow to stand for at least 48 hours to allow escape of evolved carbon dioxide to avoid hazardous pressure build-up in container.
13. KEEP OUT OF THE REACH OF CHILDREN.

Coverage Rates

Application rates may vary depending on ambient temperatures, surface, and substrate absorption rate.

Approximate Coverage Rate (Sq. Ft.)	50 Gallon Drums				
	Full Spray	4" o.c.	6" o.c.	12" o.c.	Splatter Value
	5,000 – 10,000	6,700 – 9,000	10,000 – 12,500	20,000 – 25,000	18,000 – 20,000
Approximate Coverage Rate (Sq. Ft.)	15 Gallon Drums				
	Full Spray	4" o.c.	6" o.c.	12" o.c.	Splatter Value
	1,800 – 3,000	2,110 – 2,700	3,000 – 3,750	6,000 – 7,500	5,400 – 6,000

LEED® Information

Pre-consumer Recycled Content	0%
Post-consumer Recycled Content	0%
Manufacturing Locations	Geismar, LA Elwood, IL Chattanooga, TN
VOC Content	0 g/L
Solar Reflectance Index	N/A



WEATHERBOND
ROOFING SYSTEMS

Single-Ply Simplified

Substrate Compatibility

Insulation/Underlayments		Roof Decks		Existing Roofing Materials	
XP® Polyiso	Yes	Concrete	Yes	Smooth BUR	Yes ⁵
HP Recovery Board	Yes	Cellular Lt.Wt. Concrete	Yes	Gravel BUR	Yes ⁶
Expanded Polystyrene (EPS)	Yes ¹	NVS Lt.Wt. Concrete	Yes	Mineral Cap Sheet	Yes
Extruded Polystyrene	Yes ²	Gypsum	Yes	Granular Modified-Bitumen	Yes
New Sprayed Foam	Yes	Cementitious Wood Fiber	Yes	Smooth Modified-Bitumen	Yes
Scarified SPF	Yes	Plywood/OSB	Yes	Coal Tar Pitch	Yes ⁷
DensDeck®	Yes	Painted Steel	Yes	Aluminum-Coated BUR	Yes ⁸
SECUROCK®	Yes	Galvanized Steel	Yes ³	Acrylic-Coated SPF	Yes
Oriented Strand Board	Yes	Acoustical Steel	Yes ⁴	Silicone-Coated SPF	Yes ⁹
XFP Polyiso	Yes	Wood Plank	Yes	Aged EPDM, Hypalon, TPO	Yes ^{10,12}
				Unweathered Asphalt	Yes/No ¹¹

- Fleece TPO membranes may be installed directly over minimum 1.5-lb.-density EPS; however, to obtain UL & FM codes, an overlayment of HP Recovery Board, DensDeck, Securock or XP Polyiso insulation is required.
- For insulation attachment only.
- For new galvanized steel decks, power-washing may be necessary to remove finishing oil residue if present.
- For acoustical steel decks, fill the flutes with fiberglass or other suitable fill insulation and tack in place with strips of duct tape 3' o.c., or other adhesive, prior to spraying the deck with Flexible DASH Adhesive.
- Existing Smooth BUR must be Type III or IV asphalt if the Fleece PVC and KEE HP or Fleece TPO membrane is to be installed directly without insulation.
- A minimum ½" HP Recovery Board or XP Polyiso insulation is required over properly prepared gravel BUR. Fleece membrane cannot be installed directly over a gravel/slag surface.
- An insulation providing the necessary R-value must be specified to prevent the coal tar pitch from softening. Fleece membranes cannot be installed directly to coal tar pitch.
- Any loose coatings must be removed by power-washing or by physical abrasion prior to the application of Flexible DASH Adhesive. A test installation over the aluminum-coated smooth BUR is recommended to ensure the aluminum coating is fully adhered.
- Silicone-coated substrates must be scarified (coating removed) prior to the application of Flexible DASH Adhesive.
- Power-washing aged Hypalon or TPO membrane is required prior to the application of Flexible DASH Adhesive.
- Requires CAV-GRIP III for all applications.
- Contact WeatherBond for specific requirements on TPO recover.

Typical Properties and Characteristics

Base	A-Side Polymeric Isocyanate	B-Side Surfactants and Catalysts
Mixing Ratios by Volume	1:1 Part A to Part B	
Viscosity (CPS @ 25C)	400	400
MDI Content	23%	
Avg. Net Weight	9.88 lbs/gallon	9.23 lbs/gallon
Packaging	15-gallon drum (57 L) 50-gallon drum (190 L)	15-gallon drum (57 L) 50-gallon drum (190 L)
Shelf Life	1 year	1 year*
Temperature Requirements (Substrate & Ambient)		min. 25°F (Heated Equipment) min. 25°F (Unheated Equipment)

* Typical R-value added for Fleece membrane attachment: 0.20 to 0.50 R-value. R-value may be higher as more adhesive is used on uneven surfaces.

Physical Property	Test Method	Results
Elongation	ASTM D412	150%
Modulus at 150% Elongation	ASTM D412	20 psi
Dynamic Puncture Resistance - OSB	ASTM D5635-04a	33% greater than standard DASH
Dynamic Puncture Resistance - HP Recovery Board		40% greater than standard DASH
Dynamic Puncture Resistance - Polyiso		50% greater than standard DASH



WEATHERBOND
ROOFING SYSTEMS

Single-Ply Simplified

P.O. Box 251 | Plainfield, PA 17081 | 866.471.5125 | FAX: 717.960.4034 | www.weatherbondroofing.com

© 2023 WeatherBond. WB-10765 - "Flexible DASH Adhesive TDB" 06.01.23
WeatherBond is a trademark of WeatherBond. CAV-GRIP and SecurShield are trademarks of Carlisle Construction Materials, LLC.
SECUROCK is a trademark of USG Corporation or its subsidiaries or affiliates. DensDeck is a registered trademark of Georgia-Pacific Gypsum LLC.
LEED is a registered trademark of the U.S. Green Building Council.