





PERIMETER ZONES









INSTALL PERIMETER
SHEETS OVER THE
ENTIRE OVERHANG
(PROJECTION ROOF)
AREA, EXTENDING
ONTO THE MAIN
ROOF DECK WHEN
AT THE SAME
LEVEL AS SHOWN.






NOTES:

- REFER TO WEATHERBOND SPECIFICATIONS FOR REQUIRED NUMBER OF PERIMETER SHEETS, SHEET WIDTH AND MEMBRANE FASTENING DENSITY.
- 2. HPW FASTENERS AND POLYMER SEAM PLATES ARE REQUIRED OVER STEEL DECKS.
- 3. RPS "FINGER" MUST EXTEND THE WIDTH OF THE REQUIRED PERIMETER.





MECHANICALLY ATTACHED EPDM SECUREMENT — OPTION 3 (RPS)



- APPROVED SUBSTRATE

O → SEE NOTE

MECHANICALLY ATTACHED EPDM

WBRMA-2.0C